



# GC2 Panel User Guide



ENGLISH  
(International)

## WIRELESS SECURITY SYSTEM

---

THIS PAGE INTENTIONALLY LEFT BLANK

# CONTENTS

<b>System Overview</b>	<b>5</b>
Features	5
Basic Operation	6
Sensor Types/Zones	6
Smoke, Heat, and Freeze Protection	6
Burglary Protection	6
User Codes	6
Alarms	6
Messages	6
Trouble Alerts	6
Wireless Sensors	6
Control Panel Features	7
Main Display Screens	8
Home Screen	8
Security Screen	8
Ready to Arm Screen	8
Menu Screen	8
Status Screen	8
<b>Burglary Protection</b>	<b>9</b>
Sample Floor Plan	9
Sensor Status	10
checking for closed Sensors	10
Viewing Each Sensor's Status	11
Dealing with a Sensor False Alarm	11
Sensor Bypassing	12
Force Bypass All Sensors	12
Bypassing/Un-Bypassing Sensors	12
Stay Mode	13
Entry Delay in Stay Mode	13
Quick Exit in Stay Mode	13
Silent Control in Stay Mode	14
Arming to Stay Mode	14
Away mode	15
Exit and Entry Delays in Away mode	15
Exit Delay Restart	15
Silent Control in Away Mode	15
Quick Exit in Away Mode	16
Auto Stay Mode	16
Arming to Away Mode	16
Disarming the System	17
Disarming from Stay Mode	17
Disarming from Away Mode	18
If a Burglary Alarm Occurs	18
Burglary Alarm Siren	18
Alarm Memory	18
Optional 2-Way Voice Communications	19
Key Fob: Arming and Disarming	19
Arm with a Key Fob	19
Disarm with a Key Fob	19
Activate the Emergency Alarm	19
Activate the Auxiliary Output	19
Wireless Keypad: Arming and Disarming	20
Arm with a Keypad	20
Disarm with a Keypad	20
Activate a Fire Emergency	20
Activate a Police Emergency	20
<b>Smoke, Heat and Freeze Protection</b>	<b>21</b>
Initiating a Fire Alarm Manually	21
If the Fire Alarm Sounds Automatically	21
Silencing a False Fire Alarm	21
Recommended Fire Alarm Locations	22
NFPA Standard #72	22

Do Not Mount a Smoke Alarm Here .....	23
Emergency Action Plan .....	23
<b>Emergency Functions .....</b>	<b>24</b>
24-Hour Emergency Buttons .....	24
<b>System Trouble Alerts .....</b>	<b>25</b>
Trouble Alert Icon .....	25
View the Current Trouble Alerts .....	25
Trouble Alert Beep Hold-off .....	25
<b>System Status Icons .....</b>	<b>26</b>
AC Power On .....	26
AC Power OFF .....	26
Phone Line Failure .....	26
Sounder Disabled .....	26
Low Backup Battery .....	26
Test Mode .....	26
touch screen Keypad Traffic .....	26
Cell Radio .....	26
Interior sensor open .....	26
<b>Messaging .....</b>	<b>27</b>
Displaying Messages .....	27
Reading Messages .....	27
Reading Confidential Messages .....	28
Filtering Messages .....	28
Sorting Messages .....	28
<b>Remote Control by Telephone .....</b>	<b>29</b>
Calling the System .....	29
Controlling the System Remotely .....	29
Bypassing Sensors Remotely .....	29
<b>System Toolbox .....</b>	<b>30</b>
User Management .....	30
User Code Setup .....	30
Adding a User Code .....	30
User Code Access Schedules .....	30
User Codes .....	32
Duress User Code Setup .....	32
Secret Duress Button .....	33
System History .....	33
System Test .....	34
Sensor Test .....	34
Panel Test .....	34
Telephone Test .....	35
Chime Setup .....	36
Adjusting the Brightness/Volume .....	37
Adjusting the Backlight Timeout .....	37
Cleaning the Touch Screen .....	37
Touch Screen Calibration .....	38
Set Date and Time .....	38
Display Firmware Version .....	39
Dealer Info Screen and Call Back Button .....	39
Accessing the Dealer Info Screen .....	39
Requesting a Service Call Back .....	39
<b>Installer Programmed Options .....</b>	<b>40</b>
Siren Run Time .....	40
Sensor Trigger Limit .....	40
Fire Horn Run Time .....	40
Exit Delay .....	40
Entry Delay .....	40
24-Hour Emergency Functions .....	41
Quick Arming .....	41
Quick Bypass .....	41
Quick Exit .....	41
Auto Un-bypass .....	41

---

Auto Stay .....	41
Key Fob Sound .....	41
Key Fob Disarm After Sound .....	42
Key Fob Options .....	42
Wireless Keypad Emergency Keys .....	42
Exit Delay Restart .....	42
Cancel Display .....	42
Cancel Time .....	42
Dialer Delay .....	43
2-Way Voice .....	43
Telephone Remote Control Answer .....	43
<b>Installer Specific Information .....</b>	<b>44</b>
<b>Service Information .....</b>	<b>46</b>
<b>Alarm Dialing Equipment .....</b>	<b>47</b>
<b>Regulatory Information .....</b>	<b>48</b>
Wireless Product Notice .....	48
FCC Notice .....	48
FCC Telephone Rules and Regulations .....	48
Industry Canada Notices .....	48
<b>Important Notice .....</b>	<b>50</b>
Alarm System Limitations .....	50
<b>Limited Warranty .....</b>	<b>52</b>



# SYSTEM OVERVIEW

This system provides three (3) forms of protection: burglary, fire, and emergency, depending on the options set by your installer. The system consists of the Control Panel with a color touch screen, wireless sensors that provide perimeter and interior burglary protection, and wireless smoke and carbon monoxide detectors. In addition, optional remote control key fobs, wireless panic buttons and keypads may have been provided or installed.

The system monitors all protection “zones” and the system’s status. The Control Panel displays monitoring information and controls the alarm siren. Your system may also have been setup to send alarm and status reports to a Central Station and may have the capability for 2-way voice communications with the alarm monitoring operator.

## FEATURES

Following is a list of standard features and options that can be included in your system. Ask your installer which options are available to you and check the boxes that apply.

- **Stay** and **Away** arming modes: Stay mode arms the system perimeter only and is used typically at night when the premises are occupied. Away mode arms the system perimeter and interior; it is used when the premises are unoccupied.
- 60 user-unique 4-digit codes to operate the system: The system supports one (1) *master user code* that can assign and maintain the other *user codes*.
- One of the 60 user codes functions as a *duress code*. Controlling the system with this code gives the appearance of normal operation, but using it sends a silent duress report to the Central Station to initiate a silent alarm call for help.
- Voice announcements from the Control Panel: The system has a vocabulary of descriptive words that can be assigned to sensors so each has a unique announcement such as “front door” or “bedroom window” if desired.
- Home automation with the built-in Z-Wave controller for remote control of Z-Wave enabled home appliances (optional feature).
- Alarm history with system event log: Each alarm and system alert is logged into the system’s memory. These events can be displayed and reviewed at the Control Panel or remotely by the Central Station.
- Real time clock and calendar shows on the system’s display and is used to time stamp items in the event log.
- 2-way voice communication: After an alarm, the system can automatically connect with a Central Station operator so they can converse with people in the premises.
- Remote control of the system over the telephone.<sup>1</sup>
- Remote control of the system using a Web-enabled device through the Internet.<sup>2</sup>
- Three optional 24-hour emergency functions: Panic, Fire, and Emergency. These functions can be activated by buttons on the Control Panel, using wireless sensors, from the wireless keypad, or from portable pendant devices (such as the panic button remote).

---

1. Requires the optional POTS module, which is only available in the United States and Canada.

2. Requires the optional Cellular Radio Module.